

































# Mounting instructions TurboSwing® XM & XL







  
 the power behind your outboard

Postbus 65  
 2360 AB Warmond  
 The Netherlands

Tel: +31(0)71-30 11 220  
 Fax: +31(0)71-30 10 044  
 info@turboswing.com